SPP-N1000

SERVICE MANUAL

US Model

Ver 1.0 2000.05

• The following parts are an available for service parts of this model.

PARTS LIST

Ref. No.	Part No.	Description	Remark
⚠	1-476-118-11	ADAPTOR, AC (AC-T127) (GRAY)	
⚠	1-476-118-21	ADAPTOR, AC (AC-T127) (WHITE)	
	1-696-454-11	CORD (WITH MODULAR PLUG) (LINE)	
	3-026-932-01	LABEL (ADRESS, B)	
	3-046-100-01	LID, BATTERY CASE (GRAY)	
	3-046-100-11	LID, BATTERY CASE (WHITE)	
	3-048-609-11	MANUAL, INSTRUCTION (ENGLISH, SPANISH)	
	3-936-696-21	FOOT, RUBBER	

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

CORDLESS TELEPHONE

SONY®

9-927-933-11

Sony Corporation
Audio Entertainment Group

2000E02087-1
Printed in Japan © 2000.5
Published by PE General Engineering Dept.

SPP-N1000

SERVICE MANUAL

REVISED

Ver 1.1 2001. 02

US Model

• The following parts are an available for service parts of this model.

PARTS LIST

Ref. No.	Part No.	Description	Remark
⚠	1-476-118-11	ADAPTOR, AC (AC-T127) (GRAY)	
⚠	1-476-118-21	ADAPTOR, AC (AC-T127) (WHITE)	
	1-696-454-21	CORD (WITH MODULAR PLUG) (LINE)	
	1-756-107-32	BATTERY, NICKEL CADMIUM (BP-T50)	
	3-046-100-01	LID, BATTERY CASE (GRAY)	
	3-046-100-11	LID, BATTERY CASE (WHITE)	
	3-048-609-51	MANUAL, INSTRUCTION (ENGLISH, SPANISH)	
	3-936-696-21	FOOT, RUBBER	

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

CORDLESS TELEPHONE

SONY®

9-927-933-12
2001B0200-1
© 2001.2

Sony Corporation
Audio Entertainment Group
General Engineering Dept.

SPP-N1000

SERVICE MANUAL

REVISED-2

Ver 1.2 2001. 05

US Model

• The following parts are an available for service parts of this model.

PARTS LIST

Ref. No.	Part No.	Description	Remark
⚠	1-476-118-11	ADAPTOR, AC (AC-T127) (GRAY)	
⚠	1-476-118-21	ADAPTOR, AC (AC-T127) (WHITE, BLACK, RED, YELLOW)	
	1-696-454-21	CORD (WITH MODULAR PLUG) (LINE)	
	1-756-107-32	BATTERY, NICKEL CADMIUM (BP-T50)	
	3-046-100-01	LID, BATTERY CASE (GRAY)	
	3-046-100-11	LID, BATTERY CASE (WHITE)	
	3-046-100-31	LID, BATTERY CASE (BLACK)	
	3-046-100-41	LID, BATTERY CASE (RED)	
	3-046-100-51	LID, BATTERY CASE (YELLOW)	
	3-048-609-51	MANUAL, INSTRUCTION (ENGLISH, SPANISH)	
	3-936-696-21	FOOT, RUBBER	

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

CORDLESS TELEPHONE

9-927-933-13
2001E0200-1
© 2001.5

Sony Corporation
Personal Audio Company
Shinagawa Tec Service Manual Production Group

SONY®